

Cleaning Instructions

— PermaTack No. 092 —

Materials

Cleaning solution –

Recommended Cleaning Agent for Clean Room applications:

- **NOVACLEAN™ FLOOR CLEAN.** NovaClean™ floor clean is an all purpose cleaner which has been filtered down to 0.1 microns. At the suggested dilution, the formulation can claim sodium and potassium levels detectable only in parts per billion. The low-ionic formulation will not generate a static charge. With little or no residue build-up, the cleaner will not affect the efficiency of conduction flooring. Easy and economical to use, NovaClean™ floor clean is a concentrate which will yield 60 to 128 gallons of cleaner per gallon container.

Recommended Cleaning Agent for Sterile applications:

- **IPA OR STERIS CLEANERS.** IPA (Isopropyl Alcohol) or Steris Cleaners can be used to disinfect PermaTack in a sterile environment. It is very important to note however, that both types of solutions must be diluted with distilled, deionised or filtered water. To maintain the functionality of the mat, the ratio of IPA or Steris to water should not exceed 50%.

Recommended Cleaning Agent for General Applications:

- Mix a 25% Ammonia/75% Water solution, use Windex or Simple Green All-Purpose. Other options include non-abrasive, non-oil-based cleaners with PH levels between 4 and 8.
- **DO NOT USE Spic and Span or any other abrasive cleaners.** These will leave a residue and dramatically reduce the effectiveness of the mat.
- **DO NOT USE oil-based cleaners.**

Mop – with a sponge or cloth head.

Squeegee – optional, but the mat will dry faster if a squeegee is used.

Spray bottle.

Bucket with clean water.

Method –

- Mix the cleaning solution in an applicator or spray bottle.
- Apply an even amount of cleaner on the mat.
- Wet the surface, but do not create puddles.
- Mop surface in the direction away from the entrance using short, firm, even strokes. Extra attention may be needed for high traffic and high contamination areas.
- Thoroughly rinse and ring the mop out with warm, clean water. Use the damp mop to remove any surplus cleaner from the mat and the floor if any cleaner has spilled off the mat.
- Allow to air dry.
- **WARNING: Mats are slippery when wet so remember to squeegee off to expedite drying process.**



AMERICAN
FLOOR MATS *walk well*

152 Rollins Avenue #102
Rockville, Maryland 20852
800-762-9010 / 301-881-7840 (fax)
www.americanfloormats.com