

Ultra Entry Roll Mats

Cleaning & Maintenance Instructions

Daily cleaning

Using a vacuum with a beater brush, remove surface dirt. If stone or salt particles are embedded between the surface ribs, remove using a blunt instrument (screwdriver or similar device).

Weekly cleaning

1. Pre-spray the surface of the mat with an all-purpose cleaner/degreaser, paying particular attention to areas of heavy soiling.
2. Remove chewing gum by using a commercial-grade gum remover.
3. For abundant salt build up, apply a pre-soak solution of vinegar and water (1:20), applied to the surface prior to manual or machine cleaning.
4. Perform hot water extraction (preferred) or manual cleaning as described below:
 - a. Hot water extraction: Following pre-spray, clean top surfaces in the direction of the top ribs using a Rotowash (www.rotowash.com) hot water extraction machine or similar. In areas of ingrained dirt on the etched patterns of the ribs, make additional passes until completely cleaned. Use clear water only. Commercial truck mounted hot water carpet extraction machines provide the best results and quickest drying times.
 - b. Manual cleaning: Clean the top surface using a long, handled nylon bristle deck scrub or similar brush that will not leave fibers on the mat. Scrub in both directions to clean the top of the ribs as well as the etched tread surface. Rinse with clear cold water. Allow to dry prior to use.

Periodic cleaning

Clean periodically as needed, depending on the traffic density and level of soiling.

1. Carefully lift and remove each section of the Ultra Entry one at a time. Start from the center of the installation and use a blunt instrument (screwdriver or similar tool) to lift the sections of the mat. Important: do not over stretch the sections of the matting during removal.
2. Roll up and tag each section to identify its location and orientation in the mat recess.
3. Vacuum the recess thoroughly, ensuring all stones or grit particles are removed from the recess and especially around the frames. The aluminum edging/framing may be cleaned with soap and water and allowed to air dry.
4. Replace the matting sections as originally laid, working from the edges to the center of the installation. When installing the sections at the edge of the frame, be sure to slide them under the frame lips.