

Sterile Room Autoclavable Anti-Fatigue Mats

Cleaning Instructions



Autoclave:

Lay flat in an autoclave. Clean for 20 minutes at 15 psi and 275 degrees Fahrenheit.

Manual Cleaning:

Use a mixture of hot water and a mild soap (like Ivory Liquid) with a pH between 4.0 and 9.0 and wipe the mat down.

Another option is to use a pre-moistened wipe such as Sani-Cloth HB or SANI-CLOTH® PLUS both of which have very low levels of alcohol.